



SWPTA Instructions

Installing the Batteries:

Open the back cover and insert three (3) AAA batteries (not included) following the polarity diagram. Replace the back cover.

Operation:

- 1) Hang the unit on the inside doorknob.
- 2) Move the switch to the "Chime" or "Alarm" position. A red light will blink for 30 seconds. This prevents the unit from sounding during setup. Once the blinking stops, the device is armed.
- 3) When used on metal doors and door knobs made of plastic or wood, move the sensitivity setting (located on the back of the unit) to "O" (Only Vibration). The vibration sensor will cause the Chime or Alarm to sound immediately if the door is shaken or opened.
- 4) In Chime mode, activating the unit will cause the chime to sound twice and the unit will reset itself in 30 seconds. In alarm mode, it will sound continuously for 60 seconds and rearm itself after a 6 second delay.
- 5) To turn off the unit, simply move the switch to the "Off" position.

Low Battery Warning:

The three (3) AAA batteries can last approximately 1500 hours in standby mode. If the batteries are running low, a beeping sound will indicate it is time to change the batteries.

Troubleshooting:

If the alarm is either too sensitive or not sensitive enough, please see numbers 3 and 4 above to make sure the setting is correct on the back of the unit.